




## SOFTWARE MANUAL

# VM600 MPS2 Configuration Software for Machinery Protection Systems



**Meggitt SA**  
Route de Moncor 4  
PO Box 1616  
CH - 1701 Fribourg  
Switzerland

## REVISION RECORD SHEET

Edition	Date of issue	Written / modified by	PM no.	Description	Signature
1	12.10.00	R. Meyer		First edition (Software Release 1.00)	
2	18.02.04	J. Durham R. Meyer		New edition corresponding to release V1.5.010 of MPS2 software	
3	9.6.05	R. Rice		General revision for Software Release 2.0.009	
4	31.03.06	N. Parker		Update for new corporate identity	
5	15.12.2009	P. Ward	---	Updated Installation Procedure (section 2). Also updated Customer Support information.	PW
6	16.12.2013	P. Ward	---	For VM600 MPS software version 2.5.xxx, updated 5.1.6 Managing events to include inhibit events and sensor events. Also applied the latest Meggitt style guidelines.	PW
7	12.05.2015	P. Ward	---	For VM600 MPS software version 2.6.xxx, updated to include information on the improved support for the MPC4 SIL, that is, the safety version of the MPC4 card.	PW
8	09.06.2015	P. Ward	---	For VM600 MPS software version 2.7.xxx, updated to include information on VM600 MPS rack (CPUM) security and CPUM Configurator. VM600 MPSx software privilege level information removed (as available in the VM600 MPS1 software manual).	PW

	Department	Name	Date	Signature
Technical content of original issue approved by	Development	I. Karpekin	09.06.2015	IK
	Product Management	G. Clavien	09.06.2015	GC
Document released by	Technical Publications	P. Ward	09.06.2015	PW

*The duly signed master copy of this page is stored by the Technical Publications Department of Meggitt SA and can be obtained by writing to the Technical Publications Manager.*

## **IMPORTANT NOTICE**

All statements, technical information, and recommendations in this document which relate to the products supplied by Meggitt Sensing Systems are based on information believed to be reliable, but unless otherwise expressly agreed in writing with Meggitt SA the accuracy or completeness of such data is not guaranteed. Before using this product, you must evaluate it and determine if it is suitable for your intended application. Unless otherwise expressly agreed in writing with Meggitt SA, you assume all risks and liability associated with such use. Meggitt Sensing Systems takes no responsibility for any statements related to the product which are not contained in a current English language Meggitt Sensing Systems publication, nor for any statements contained in extracts, summaries, translations or any other documents not authored and produced by Meggitt Sensing Systems.

## **EXPORT CONTROL**

The information contained in this document may be subject to export control regulations of the European Community, USA or other countries. Each recipient of this document is responsible for ensuring that the transfer or use of any information contained in this document complies with all relevant export control regulations. ECN N/A.

## **COPYRIGHT**

Copyright© 2000-2015 Meggitt SA

All rights reserved

Published and printed by Meggitt SA in Fribourg, Switzerland

The names of actual companies and products described herein may be the trademarks of their respective owners.

The information contained in this document is subject to change without notice. This information shall not be used, duplicated or disclosed, in whole or in part, without the express written permission of Meggitt Sensing Systems.

THIS PAGE INTENTIONALLY LEFT BLANK

## PREFACE

### About this manual

This manual relates to the VM600 MPS2 Configuration Software, from Meggitt Sensing Systems' Vibro-Meter® product line. It explains how to install and begin using the software, and provides instructions on configuring the system.

---

**NOTE:** This document should be read in conjunction with the following Meggitt Sensing Systems (MSS) manuals:

- *VM600 Machinery Protection System (MPS) hardware manual*
- *VM600 Networking manual.*

---

For information on the VM600 MPS1 Configuration Software, refer to the *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual.

The VM600 MPSx software (that is, MPS1 and MPS2) includes context-sensitive offline help. This means that the help is installed locally on the computer (when the software is installed) and that the text that appears depends on which part of the software is being displayed at the time.

### About Meggitt, Meggitt Sensing Systems and Vibro-Meter

Headquartered in the UK, Meggitt PLC is a global engineering group specialising in extreme environment components and smart sub-systems for aerospace, defence and energy markets.

Meggitt Sensing Systems is the operating division of Meggitt specialising in sensing and monitoring systems, which has operated through its antecedents since 1927 under the names of ECET, Endevco, Ferroperm Piezoceramics, Lodge Ignition, Sensorex, Vibro-Meter and Wilcoxon Research. Today, these operations are integrated under one strategic business unit called Meggitt Sensing Systems, headquartered in Switzerland and providing complete systems, using these renowned brands, from a single supply base.

The Meggitt Sensing Systems facility in Fribourg, Switzerland was formerly known as Vibro-Meter SA, but is now Meggitt SA. This site produces a wide range of vibration and dynamic pressure sensors capable of operation in extreme environments, leading-edge microwave sensors, electronics monitoring systems and innovative software for aerospace and land-based turbo-machinery. This includes the VM600 MPSx Configuration Software (MPS2 software) produced for the Vibro-Meter product line.

### Who should use this manual?

This manual is intended for operators of machinery protection systems using the VM600 MPS2 software.

---

**NOTE:** The architectural aspects of the MPS2 software (**Database > View > Architectural** option) are described in *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual.

---

## Applicability of this manual

---

**NOTE:** This manual applies to version 2.7.xxx of the VM600 MPS2 software. It reflects the features available with version 2.7.xxx and may not be applicable to earlier or later versions of the software.

---

## Terminology

---

**NOTE:** The MPC4 machinery protection card is available in different versions, including a standard version, a separate circuits version and a safety (SIL) version.

---

The MPC4 SIL (safety MPC4 card) was developed to permit a wider range of installation options with a single VM600 rack, for example, condition monitoring in addition to machinery protection. Accordingly, the MPC4 SIL does not have a VME bus interface and can only be configured via a direct connection to the RS-232 connector on its front panel (even for a “networked” VM600 rack), in order to reduce the possibility of corruption of its configuration. In addition, the MPC4 SIL does not provide all of the signal processing capabilities of the standard and the separate circuits versions of the MPC4. Refer to the *MPC4 machinery protection card* data sheet and the *VM600 Machinery Protection System (MPS)* hardware manual for further information.

---

**NOTE:** Previously, the VM600 MPSx software referred to all versions of the MPC4 card as MPC4. Starting with VM600 MPSx software version 2.6, the VM600 MPSx software makes a distinction between different versions of the MPC4 card by referring to both the standard version and the separate circuits version of the MPC4 card as an **MPC4** and referring to the safety version of the MPC4 card as an **MPC4 SIL**.

---

For example, when adding an MPC4 card to a VM600 rack configuration, the user must select either:

- **MPC4** – to add a standard or a separate circuits MPC4 card.
- **MPC4 SIL** – to add a safety MPC4 card.

This distinction continues throughout the VM600 MPSx software, where MPC4 cards are listed as either MPC4 or MPC4 SIL.

In general, MPC4 is used in this manual to refer to all versions of the card. However, where it is necessary to make a distinction, MPC4 is used to indicate both the standard and separate circuits versions of the card and MPC4 SIL is used to indicate the safety version.

## Related publications and documentation

Related documents from Meggitt Sensing Systems (MSS) are:

- *VM600 Machinery Protection System (MPS)* hardware manual (MSS document ref. MAMPS-HW/E).
- *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual (MSS document ref. MAMPS1-SW/E).
- *MPC4 machinery protection card* data sheet (MSS document ref. 268-021).
- *AMC8 analog monitoring card* data sheet (MSS document ref. 268-041).

Operators of networked VM600 MPSs should also refer to the following document:

- *VM600 Networking* manual  
(MSS document ref. MAVM600-NET/E).

Operators of safety-related systems (SRSs) should also refer to the following document:

- *VM600 Functional Safety* manual  
(MSS document ref. MAVM600-FS/E).

## Release notes

Before using the MPS2 software, read the *Release Notes* provided with the MPS2 Software Installation Kit. The release notes are contained in a file called `ReleaseNotes.pdf` on the CD. The *Release Notes* contain information on:

- New features of the latest version
- Resolved problems, known issues and bug fixes
- Compatibility with earlier software versions.

THIS PAGE INTENTIONALLY LEFT BLANK

## SAFETY

### Symbols and styles used in this manual

The following symbols are used in this manual where appropriate:



#### The **WARNING** safety symbol

**THIS INTRODUCES DIRECTIVES, PROCEDURES OR PRECAUTIONARY MEASURES WHICH MUST BE EXECUTED OR FOLLOWED. FAILURE TO OBEY A WARNING CAN RESULT IN INJURY TO THE OPERATOR OR THIRD PARTIES.**



#### The **CAUTION** safety symbol

**This draws the operator's attention to information, directives or procedures which must be executed or followed. Failure to obey a caution can result in damage to equipment.**

---

**NOTE:** This is an example of the NOTE paragraph style. This draws the operator's attention to complementary information or advice relating to the subject being treated.

---

THIS PAGE INTENTIONALLY LEFT BLANK

# TABLE OF CONTENTS

<b>TITLE PAGE</b> .....	<b>i</b>
<b>REVISION RECORD SHEET</b> .....	<b>ii</b>
<b>PREFACE</b> .....	<b>v</b>
<b>SAFETY</b> .....	<b>ix</b>
<b>TABLE OF CONTENTS</b> .....	<b>xi</b>
<b>1 INTRODUCTION</b> .....	<b>1-1</b>
1.1 What is MPS2? .....	1-1
1.2 Differences between the MPS1 and MPS2 software .....	1-1
1.3 Offline help .....	1-2
1.4 Tool tips .....	1-2
<b>2 INSTALLING THE SOFTWARE</b> .....	<b>2-1</b>
2.1 Before starting .....	2-1
2.1.1 Items delivered .....	2-1
2.1.2 System requirements .....	2-1
2.2 Installation procedure .....	2-2
2.3 Removing an old version of the software .....	2-4
2.3.1 Precautions concerning databases .....	2-4
2.3.2 Removing the software .....	2-5
<b>3 GETTING STARTED</b> .....	<b>3-1</b>
3.1 Starting the VM600 MPS2 software .....	3-1
3.2 VM600 MPSx software privilege levels .....	3-2
3.3 VM600 MPS rack (CPUM) security .....	3-3
3.4 CPUM Configurator software .....	3-4
<b>4 USING VM600 MPS2 FOR CONDITION MONITORING</b> .....	<b>4-1</b>
4.1 Introduction .....	4-1
4.1.1 Configuration trees (Architectural and Logical) .....	4-1
4.1.2 Acquiring and storing data for trend analysis .....	4-1
4.1.3 Real-time analysis .....	4-2

4.2	Creating the Logical configuration tree . . . . .	4-3
4.2.1	Creating databases . . . . .	4-3
4.2.2	Attributing a station to a database . . . . .	4-4
4.2.3	Attributing machines to a station . . . . .	4-5
<b>5</b>	<b>MANAGING DATABASES, STATIONS AND MACHINES . . . . .</b>	<b>5-1</b>
5.1	Managing databases . . . . .	5-1
5.1.1	Performing consistency checks . . . . .	5-2
5.1.2	Managing database data . . . . .	5-3
5.1.3	Obtaining privileges . . . . .	5-4
5.1.4	Starting and stopping data acquisition . . . . .	5-4
5.1.5	Using the Database Manager . . . . .	5-4
5.1.6	Managing events . . . . .	5-5
5.2	Managing stations . . . . .	5-8
5.3	Managing machines . . . . .	5-9
5.3.1	Configuring information at machine level . . . . .	5-10
5.3.2	Configuring timing information . . . . .	5-13
5.3.3	Displaying event information at machine level . . . . .	5-15
<b>6</b>	<b>STORING ACQUIRED VALUES IN THE DATABASE . . . . .</b>	<b>6-1</b>
6.1	Introduction . . . . .	6-1
6.2	Creating the Architectural and Logical configuration trees . . . . .	6-1
6.3	Configuring machines . . . . .	6-1
6.4	Starting the acquisition and storage of data . . . . .	6-2
6.5	Modifying the Architectural structure of a VM600 MPS . . . . .	6-2
<b>7</b>	<b>DISPLAYING DATA IN REAL-TIME . . . . .</b>	<b>7-1</b>
7.1	Introduction . . . . .	7-1
7.2	Displaying bar charts . . . . .	7-1
7.2.1	Overview . . . . .	7-1
7.2.2	Modifying the presentation of a bar chart . . . . .	7-3
7.2.3	Drop-down menu commands for bar charts . . . . .	7-7
7.3	Displaying strip charts . . . . .	7-7
7.3.1	Overview . . . . .	7-7
7.3.2	Drop-down menu commands for strip charts . . . . .	7-11
7.3.3	Sizing, repositioning and zooming . . . . .	7-13

<b>8</b>	<b>DISPLAYING HISTORICAL DATA</b>	<b>8-1</b>
8.1	Introduction	8-1
8.2	Displaying historical trend charts	8-1
8.2.1	Overview	8-1
8.2.2	Drop-down menu commands for trend charts	8-4
8.3	Displaying averages trend charts	8-6
8.3.1	Overview	8-6
8.3.2	Further information	8-8
<b>9</b>	<b>CUSTOMER SUPPORT</b>	<b>9-1</b>
9.1	Contacting us	9-1
9.2	Technical support	9-1
9.3	Sales and repairs support	9-1
9.4	Customer feedback	9-2

## **FAILURE REPORT FORM**

## **CUSTOMER FEEDBACK FORM**

THIS PAGE INTENTIONALLY LEFT BLANK

# 1 INTRODUCTION

## 1.1 What is MPS2?

MPS2 is a configuration software package for VM600 machinery protection systems, from Meggitt Sensing Systems' Vibro-Meter® product line. It is used to configure VM600 MPS hardware as well as to collect data for condition monitoring purposes.

## 1.2 Differences between the MPS1 and MPS2 software

### MPS1

The VM600 MPS1 Configuration Software package (MPS1 software) was developed to enable the complete configuration of a VM600 machinery protection system. It allows the user to adapt the VM600 hardware to the types of transducer or conditioner being used, to define the type of signal processing, to set alarm levels and to read the measured values.

The VM600 MPS1 software uses an “architectural” approach to configure a VM600 MPS. To enable this configuration step, the operator must first define a *configuration tree structure* for the VM600 MPS containing databases, racks and individual cards. The configuration tree reflects the true hardware architecture of the VM600 MPS.

### MPS2

The VM600 MPS2 Configuration Software package (MPS2 software) is intended mainly to be used with condition monitoring solutions. However, it also contains all the functionality provided by the VM600 MPS1 software. These functions are accessed either by clicking the **Architectural View** button at the bottom left-hand corner on the main window of the VM600 MPS2 Configuration Editor (VM600 MPSx software), or by selecting the **View > Architectural** option from the **Database** drop-down menu.

The additional condition monitoring features, which are available only in the VM600 MPS2 software, are accessed either by clicking the **Logical View** button at the bottom left-hand corner of the main window (VM600 MPS2 Configuration Editor), or by selecting the **View > Logical** option from the **Database** menu, as shown in Figure 1-1. The term “logical” is used here because this feature of the VM600 MPS2 software is used to sub-divide each database logically into stations and machines. This structure does not necessarily reflect the true architecture of the underlying VM600 MPS hardware.




Figure 1-1: Selection of the Architectural View or Logical View

The **Architectural View / Logical View** button bar enables you to switch quickly between the two views, and is shown below in Figure 1-2.



Figure 1-2: Architectural View / Logical View button bar

### 1.3 Offline help

The VM600 MPSx software (MPS2) includes offline help that is installed locally on the computer. This help provides text that relate to windows within the software. You can obtain a help topic window by clicking the **Help** button on the splash screen, as shown in Figure 1-3, or by pressing the **F1** key at any time while using the software.




Figure 1-3: Help button on the splash screen

Choose the **Show Index** button on the Help Topic window to obtain a list of topics (the Help Index window appears).

You can also access the Help Index window by choosing Contents from the **Help** drop-down menu, as shown in Figure 1-4.



Figure 1-4: Help drop-down menu

### 1.4 Tool tips

The software also includes tool tips which help the user when entering values in some fields. If the user enters an invalid value in a field, a tool tip appears giving the range of accepted values.

## 2 INSTALLING THE SOFTWARE

### 2.1 Before starting

#### 2.1.1 Items delivered

For first-time installation, you should have received the following items:

- One CD containing:
  - VM600 MPS2 Configuration Software
  - An electronic version of the software manual (.pdf file):  
*VM600 MPS2 Configuration Software for Machinery Protection Systems*  
(MSS document ref. MAMPS2-SW/E)
  - Release and Installation Notes (.doc file)
- One paper copy of the software manual:  
*VM600 MPS2 Configuration Software for Machinery Protection Systems*  
(MSS document ref. MAMPS2-SW/E)
- One RS-232 communication cable.

For a software update, you receive only the following item:

- One CD containing:
  - VM600 MPS2 Configuration Software
  - An electronic version of the software manual (.pdf file):  
*VM600 MPS2 Configuration Software for Machinery Protection Systems*  
(MSS document ref. MAMPS2-SW/E)
  - Release and Installation Notes (.pdf file).

---

**NOTE:** All original CDs should be stored in a safe place once the software installation has been performed.

---

#### 2.1.2 System requirements

The VM600 MPS2 software may be installed on most modern personal computers or laptops. The following minimum computer configuration is required to run the software:

- Microsoft® Windows® Server 2003, Windows NT, Windows 2000, Windows XP, Windows Vista or Windows 7 operating system
- 200 MHz 32-bit (x86) processor or equivalent
- 32 MB system memory (RAM)
- At least 200 MB of hard disk space
- 16-colour VGA display
- One 9-pin serial port (RS-232)
- Ethernet or Fast Ethernet network card (TCP/IP)
- CD/DVD drive
- Optional 100 GB (or larger) backup media.

## 2.2 Installation procedure

---

**NOTE:** Save your work and exit (close) all applications before beginning the installation.

---


The procedure below is valid for first-time installation of the VM600 MPSx software as well as for subsequent installation of software releases.

---

**NOTE:** It is essential that you remove any previous versions of the software before installing the new version. See 2.3 Removing an old version of the software. Removing a previous version of the software does not remove any user-defined databases.

---


- 1- Insert the CD containing the VM600 MPS2 software in the CD/DVD drive of your computer.  
The installation process should start automatically. If this is the case, the VM600 MPS2 InstallShield Wizard starts (the initial window of which is shown in Figure 2-1). Go to step 5.  
If the process does not start automatically, go to step 2.
- 2- Choose **Start > Run** from the Windows task bar.
- 3- Use the Browse function to find the executable file `setup.exe` in the root directory of the CD.
- 4- Double-click the `setup.exe` file to start the VM600 MPS2 InstallShield Wizard (see Figure 2-1).



**Figure 2-1:** Welcome window of the VM600 MPS2 InstallShield Wizard

- 5- Follow the instructions given by the wizard to install the software.  
As part of the installation process, the wizard displays a Customer Information window that, among other information, asks you to enter the Serial Number of your software.


If you accept the default Serial Number (BASIC MPS), the VM600 MPSx software licence is not validated and a demonstration version of the software will be installed (see Figure 2-2). This may consist of a limited set of features.



The screenshot shows the 'InstallShield Wizard' window with the 'Customer Information' section. The text reads: 'Please enter your information.' Below this, it says: 'Please enter your name, the name of the company for which you work and the product serial number.' There are three input fields: 'User Name:' with the value 'VM600\_User', 'Company Name:' with the value 'Vibro-Meter SA', and 'Serial Number:' with the value 'BASIC MPS'. At the bottom, there are three buttons: '< Back', 'Next >', and 'Cancel'.

**Figure 2-2:** Customer Information window showing the default Serial Number

The CD Key, which is found on the back of the product CD case, must be entered as the Serial Number (see Figure 2-3). This is necessary to validate the VM600 MPSx software licence and unlock the functionality offered by VM600 MPS2, that is, VM600 trending operations.



The screenshot shows the 'InstallShield Wizard' window with the 'Customer Information' section. The text reads: 'Please enter your information.' Below this, it says: 'Please enter your name, the name of the company for which you work and the product serial number.' There are three input fields: 'User Name:' with the value 'Ward Peter', 'Company Name:' with the value 'Vibro-Meter SA', and 'Serial Number:' with the value '8601M84UK1TKTE3R700d'. At the bottom, there are three buttons: '< Back', 'Next >', and 'Cancel'.

**Figure 2-3:** Customer Information window showing an example valid Serial Number (CD Key)

---

**NOTE:** If a valid CD Key to activate the VM600 MPS2 software is not entered, the software is limited to the free-of-charge VM600 MPS1 functionality.

---

6- Define the location where the software is to be installed on the hard disk. The following default destination folder is proposed:

C:\Program Files\VM600\_MPS

An alternative folder can be chosen if desired.


---

**NOTE:** The default location for the Windows Program Files folder depends on the operating system installed on the computer:

C:\Program Files on 32-bit versions of Windows, but

C:\Program Files (x86) on 64-bit versions of Windows.

---

A VM600 MPS2 icon  (shortcut) appears on the Windows desktop when the installation is complete.

## 2.3 Removing an old version of the software

---

**NOTE:** Save your work and exit (close) all applications before removing an old version of the software.

---

### 2.3.1 Precautions concerning databases

---

**NOTE:** Removing a previous version of the software does not remove any user-defined databases.

However, as an extra precaution, it is recommended to make a backup copy of your database(s) before removing any software.

This copy can later be removed after checking that the software upgrade has been performed correctly.

---

Data is stored in database directories having a .db file name extension. Unless an alternative destination folder was chosen, these directories are found in the following default folder:

C:\Program Files\VM600\_MPS

---

**NOTE:** The default location for the Windows Program Files folder depends on the operating system installed on the computer:

C:\Program Files on 32-bit versions of Windows, but

C:\Program Files (x86) on 64-bit versions of Windows.

---

You should make a (temporary) copy of these database directories elsewhere on your computer. Do not put them under C:\Program Files\VM600\_MPS.

### 2.3.2 Removing the software

Use the procedure below to remove an old version of the software before installing a newer version:


- 1- Choose **Add or Remove Programs** from the Windows **Control Panel**.
- 2- Select **Change or Remove Programs**.
- 3- Highlight the application (VM600 MPS software) and click the **Remove** button.

**THIS PAGE INTENTIONALLY LEFT BLANK**

## 3 GETTING STARTED

### 3.1 Starting the VM600 MPS2 software

To start the VM600 MPS2 software:

- 1- Double-click the MPS2 icon  on your desktop.

This icon was created during the installation of the software. If for some reason it does not appear on the desktop, click **Start > Programs > VM600 MPS Software > MPS2**, or navigate to the **VM600\_MPS\Bin** directory on the computer's hard disk and double-click the `mps2.exe` file.

The VM600 MPS2 splash screen (window) appears, as shown in Figure 3.1.



Figure 3-1: VM600 MPS2 splash screen

- 2- Choose the working language from the drop-down menu in the top, left-hand corner of the window, as shown in Figure 3-2. The selected language is used by default the next time the VM600 MPS2 software is started:




Figure 3-2: Language drop-down menu

- 3- Click the **Begin** button, which is found below the **Language** menu.  
The main VM600 MPS2 Configuration Editor window appears, as shown in Figure 3-3:




Figure 3-3: Main window of the VM600 MPS2 Configuration Editor (VM600 MPSx software)

### 3.2 VM600 MPSx software privilege levels

As shown in Figure 3-4, the VM600 MPSx software implements a system of privileges (user access rights) to control and limit the functionality of the software available to different levels of user.




Figure 3-4: VM600 MPSx software privilege levels

The VM600 MPSx software has four levels of privilege: Read, User, Master and Super. The User, Master and Super levels are password protected in order to help prevent accidental changes or unauthorised access to the configuration of a VM600 MPS.

The VM600 MPSx software privileges levels are described in detail in the *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual.

In addition to the VM600 MPSx software's system of privileges, a VM600 MPS containing a CPUM card can implement additional rack security features (see 3.3 VM600 MPS rack (CPUM) security).


### 3.3 VM600 MPS rack (CPUM) security

As shown in Figure 3-5, a VM600 MPS in a 19" system rack (ABE04x) containing a CPUM card can implement specific rack security features in order to limit the functionality of the MPS that are available via the CPUM to Ethernet-based connections, such as the VM600 MPSx software, the CPUM Configurator software or a Modbus TCP connection.

---

**NOTE:** See 3.4 CPUM Configurator software for further information on the CPUM Configurator software.

---



**Figure 3-5:** VM600 MPS rack (CPUM) security

The use of the CPUM security features (CPUM access lock and MPS password validation) is recommended in order to help prevent accidental or unauthorised access to a VM600 MPS configuration and other MPS system functionality, thereby reducing the possibility of interference in the operation of the MPS and the machinery being monitored.

MPS rack (CPUM) security is described in detail in the *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual.

The VM600 MPS rack (CPUM) security features are in addition to the VM600 MPSx software's system of privileges (see 3.2 VM600 MPSx software privilege levels).

### 3.4 CPUM Configurator software

CPUM Configurator is a program that communicates with a CPUM card in a VM600 rack over an Ethernet (TCP/IP) link. Basically, it provides a graphical user interface for a Telnet session between a CPUM Configurator (Telnet client) and a CPUM card (Telnet server), and is used primarily for configuring and managing CPUM cards / VM600 racks

---

**NOTE:** Refer to the *VM600 Networking* manual for further information on the CPUM Configurator software.

---

## 4 USING VM600 MPS2 FOR CONDITION MONITORING

### 4.1 Introduction

This section explains how to configure the VM600 MPS2 software to perform conditioning monitoring.

It is assumed in this section, and everywhere else in this manual, that the “architectural” structure of the database(s) has already been created. This will have been done using either of the following:

- The VM600 MPS1 software.
- The VM600 MPS2 software with the **View > Architectural** option chosen from the **Database** drop-down menu.

---

**NOTE:** The architectural aspects of the VM600 MPS1 software are fully described in the *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual.

---

#### 4.1.1 Configuration trees (Architectural and Logical)

It is essential to create an architectural configuration tree structure to define the VM600 MPS hardware architecture. The following steps enable you to do this:

- 1- Choose the **View > Architectural** option from the **Database** drop-down menu, or click the button in the bottom left-hand corner of the window.  
This tree has a structure and hierarchy similar to that shown in Figure 4-1 (a). In this example there are  $n$  databases.
- 2- Attribute the VM600 racks used in the protection system to the various databases as required.
- 3- Define the cards (MPC4, MPC4 SIL, AMC8 and so on) used in each VM600 rack, along with the slot position they occupy.
- 4- Configure the inputs and outputs of the individual cards
- 5- Build the logical configuration tree structure by selecting the **View > Logical** option from the **Database** drop-down menu, or click the button in the bottom left-hand corner of the window.

The structure and hierarchy of this tree are shown in Figure 4-1 (b).

---

**NOTE:** The number of databases will be the same as those defined in the architectural configuration tree ( $n$  in this example).

---

- 6- You can now attribute stations to each database.  
A station can correspond, for example, to a particular group of machines that are monitored by the VM600 MPS.
- 7- Define the machines which make up each station.

#### 4.1.2 Acquiring and storing data for trend analysis

When the logical structure of the VM600 MPS has been defined, the VM600 MPS2 software can be configured to acquire and store measured values in the database(s). This data can be


recalled later for trend analysis. Trend information obtained in this way provides a useful tool to help perform predictive maintenance of the machine being monitored.

**NOTE:** See 6 Storing acquired values in the database for further information on acquiring and storing data for subsequent trend analysis. 8 Displaying historical data describes how to display trend data.

### 4.1.3 Real-time analysis

As well as providing trend information on stored values, the VM600 MPS2 software allows real-time display and analysis of measured values. These values may be displayed in the form of Bar Charts and Strip Charts.

**NOTE:** See 7 Displaying data in real-time for further information on real-time display and analysis of measured values.



**Figure 4-1:** Structure and hierarchy of Architectural and Logical configuration trees

## 4.2 Creating the Logical configuration tree

This section describes how to create the logical configuration tree. This defines the overall logical structure of the protection system, rather than the architectural structure which is defined by the hardware.

### 4.2.1 Creating databases

A database (or several databases) will normally have already been created when the architectural configuration tree was created. An additional database can nevertheless be created when the **View > Logical** option is chosen from the **Database** drop-down menu.

To create a database:

- 1- Select **New Database** from the **Database** drop-down menu at the top of the main window (VM600 MPS2 Configuration Editor).

A dialog box as shown in Figure 4-2 appears.

- 2- Enter a name for the database in the **Tag** field.

This name must be unique, that is, no two databases can have the same name.

Some descriptive text can be entered in the **Description** field to provide further information. Any text entered is visible as a cue card when the mouse pointer is placed on the icon in the configuration tree representing the database.

The **Current Folder** line displays the folder on the hard disk in which the database is stored. Click **Change Folder** to store the database in a different folder:




Figure 4-2: New Database dialog box

Figure 4-3 shows the appearance of a configuration tree with two databases created.





Figure 4-3: Configuration tree showing two databases

You can use Windows Explorer to look at the contents of the VM600 MPS2 directory on the hard disk. By default, databases are stored in the \Configuration sub-directory and have the .db file name extension, as shown in Figure 4-4.



**Figure 4-4:** VM600 MPS2 software database directories viewed with Windows Explorer


### 4.2.2 Attributing a station to a database

You must attribute a station (a specific machine or group of machines) to a database. You can do this in one of two ways.

- 1- Either:
  - a. Select the Logical View.
  - b. In the logical configuration tree, select the database that is to store the station’s data.
  - c. Select **New Station** from the **Database** drop-down menu. The New Station dialog box appears (Figure 4-6).


or

  - a. Select the Logical View.
  - b. In the logical configuration tree, select the database that is to store the station’s data.
  - c. Right-click to obtain the menu shown in Figure 4-5, and choose the **New Station** command.



**Figure 4-5:** Adding a station to a database

The New Station dialog box appears (see Figure 4-6).



**Figure 4-6:** New Station dialog box

- 2- Enter a name for the station in the **Tag** field.

This name must be unique: that is, no two stations in the system can have the same name.

Some descriptive text can be entered in the **Description** field to provide further information. This text is visible as a cue card when the mouse pointer is placed on the icon in the configuration tree representing the station.

- 3- Click **OK** to close the dialog box.

### 4.2.3 Attributing machines to a station


To attribute machines to a station, first highlight the station name in the logical configuration tree using the left mouse button. You can do this in one of two ways.

- 1- Either:

- Select **Add Machine to Station** from the **Database** drop-down menu. The New Machine dialog box appears (see Figure 4-8).


or

- Right-click the rack to display the menu shown in Figure 4-7, and choose **Add Machine to Station**.



**Figure 4-7:** Adding a machine to a station

The New Machine dialog box appears.




**Figure 4-8:** New Machine dialog box

- 2- Enter a name for the machine in the **Tag** field.

This name must be unique: that is, two or more machines cannot have the same name. Some descriptive text can be entered in the **Description** field to provide further information. This text is visible as a cue card when the mouse pointer is placed on the icon in the configuration tree representing the station.

- 3- Click **OK** to close the dialog box.

Figure 4-9 shows a typical logical configuration tree once several machines and stations have been assigned to databases.



**Figure 4-9:** Logical configuration tree containing several stations and machines


## 5 MANAGING DATABASES, STATIONS AND MACHINES

This chapter describes how to declare and configure:

- Databases
- Stations
- Machines.

### 5.1 Managing databases

If a database is selected from the logical configuration tree, the main window (VM600 MPS2 Configuration Editor) resembles that shown in Figure 5-1.



On the right-hand side of the window, two tabs are available:

- Selected by default, The **General Info** tab shows information about the currently selected database:
  - **Tag**  
Allows the database name to be changed.
  - **Description**  
Optionally, some descriptive text can be entered here. This text is visible when the mouse pointer is placed on the database icon in the configuration tree.
- The **Event Info** tab shows information about events (see 5.1.6 Managing events).

### 5.1.1 Performing consistency checks


Consistency checks are used to check the validity of the files in the selected database.

To perform consistency checks, choose **Database > Consistency Checks > Perform Checks**.

The VM600 MPS2 software also performs consistency checks automatically whenever:

- Optionally, starting the VM600 MPS2 software for the first time.
- Switching to the Super privilege level (see 3.2 VM600 MPSx software privilege levels).
- Closing (exiting) the Database Manager utility (see 5.1.5 Using the Database Manager).
- Switching between Logical and Architectural views (see 4.1.1 Configuration trees (Architectural and Logical)).


The Consistency Checks window is displayed, as shown in Figure 5-2.



**Figure 5-2:** Consistency Checks window displaying previous results

The Consistency Checks window lists the results of a number of checks that the VM600 MPS2 software carries out on the current database:



- Verifying that read/write access is granted to all database files.
- Checking that the `dbinfo.db` file exists.
- Converting rack files created with previous versions of the VM600 MPSx software to the latest version.
- Checking for file extension mismatches in early machine files.
- Searching for blank tags in MPC and AMC configurations.
- Checking for AMC Board Level information problems due to the incorrect initialisation of remote source channels 1 and 2 (**Remote Channel Source #1** and **#2**).

If any errors or inconsistencies are found, the VM600 MPS2 software can automatically perform any database updates necessary. It is strongly recommended that you request automatic updates. Click the  icon on the toolbar of the Consistency Checks window to perform automatic updates.

The results of previous consistency checks are stored in order to allow you to refer to them subsequently. You can use the following commands on the **Database > Consistency Checks** menu to manage the results of previous consistency checks:

- **View Previous Results**

Displays the last Consistency Check file(s) created for the current database. You can step back through earlier files by clicking the 'Back' button on the toolbar (see Figure 5-2).

Alternatively, you can click the  and  icons on toolbar of the Consistency Checks window to display the previous and next set of results, respectively.

- **Clear Previous Results**

Deletes all Consistency Check files created for the current database.

Alternatively, click the icon on the Consistency Checks window to display the previous results.

### 5.1.2 Managing database data

You can use the following commands on the **Database** menu to manage data:

- **Delete Data**

Deletes all data from the selected database, but keeps the structure of the database.

- **Delete All Stations**

Deletes all defined stations from both the selected database and the hard disk. This action requires confirmation.

- **Refresh Data Files**

Ensures that the data files are consistent with respect to the architectural information contained in the database.

- **Database Manager**

Lets you perform database file operations. See 5.1.5 Using the Database Manager for descriptions of the available commands.

- **Refresh Database Files**

Updates the version information in the selected database to the latest release and performs any necessary updates. If some information cannot be updated, a window is displayed indicating which database files could not be updated (the most likely reason is that the database file is open in another program and its read-only attribute is therefore set).

### 5.1.3 Obtaining privileges

The **Privileges** drop-down menu allows you to set the privilege levels and to change passwords.

Privilege levels are described in detail in 3.2 VM600 MPSx software privilege levels.

### 5.1.4 Starting and stopping data acquisition

The start acquisition and stop acquisition buttons in the toolbar activate and deactivate the acquisition and storage of data in the databases, respectively.

If several databases exist, you cannot selectively activate only one of them.

When data is being acquired and stored, the database status flag at the bottom of the window (see Figure 5-1) is green. It becomes red when no acquisition and storage is taking place.

### 5.1.5 Using the Database Manager

The Database Manager allows you to manage the databases created to contain VM600 MPS configuration data.

To start the Database Manager, click **Database > Database Manager** when you are at Database Level.

The window in Figure 5-3 opens, listing the databases and providing access to the database operations available in the VM600 MPS2 software.




Figure 5-3: Database Manager window

The VM600 MPS2 Database Manager provides the commands listed in Table 5-1.

**Table 5-1:** Database Manager commands

Command	Description
<b>Copy DB</b>	Creates a copy of the selected database and adds it to the active DB list.
<b>Move DB</b>	Moves the selected database to another location on your file system, and keeps it in the active DB list.
<b>Delete DB</b>	Deletes the selected database and all related files and removes it from the active DB list.
<b>Details</b>	Shows a list of all files in the selected database, their content and version.
<b>Help</b>	Displays the On-line Help information.
<b>Search</b>	Searches the specified drive for a valid VM600 MPS database.
<b>Disable All</b>	Disables all databases in the active DB list.
<b>Enable All</b>	Enables all databases in the active DB list.
<b>Save</b>	Saves changes in the active DB list (applies to enabled databases only).
<b>Close</b>	Closes (exits) the Database Manager window.

### 5.1.6 Managing events

You can display information about the different classes (types) of events that occur and are recorded in the database:

- Diagnostic events.
- Alarm events.
- Inhibit events.
- Sensor events.

---

**NOTE:** Each database used by the VM600 MPS software contains a circular buffer for the storage of all events and event information. This events buffer is limited to a maximum size of 1000 events, so the oldest events are deleted in order to create space for the new events (when more than 1000 events have been generated by the machinery monitoring system for a database).

---

#### 5.1.6.1 Diagnostic events

Diagnostic events include:

- Start (time at which a series of acquisitions started).
- Stop (time at which a series of acquisitions ended).
- Configuration download.
- Configuration upload.
- Configuration modification.

### 5.1.6.2 Alarm events

Alarm events are listed in chronological order. The exact date and time of the alarm are indicated, as well as the following:

- The class of alarm, including:
  - **Normal**
  - **A+** (Alert+)
  - **A-** (Alert-)
  - **D+** (Danger+)
  - **D-** (Danger-)
  - **OK**.
- Station name (the name entered in the **Tag** field of the General Info tab at station level).
- Machine name (the name entered in the **Tag** field of the General Info tab at machine level).
- Point name (with the **Database > View > Architectural** option chosen, this is the name entered in the **Tag** field when the Processed Output \ General window is displayed for Processing Channel *n* (see example in Figure 5-9).

### 5.1.6.3 Inhibit events

Inhibit events include:

- Inhibit On – generated when the channel inhibit function is activated for an input channel.
- Inhibit Off – generated when the channel inhibit function is de-activated for an input channel.

---

**NOTE:** The MPS software packages and Modbus can be used to send channel inhibit commands to individual input channels in order to temporarily bypass a sensor and the processing associated with it.

---

### 5.1.6.4 Sensor events

Sensor events include:

- Sensor OK – generated when the DC voltage of a sensor goes inside the OK levels configured for the sensor.
- Sensor Fail – generated when the DC voltage of a sensor goes outside the OK levels configured for the sensor.

---

**NOTE:** The OK levels are defined using the Upper OK Level and the Lower OK Level for an input channel in the Architectural View.

---

### 5.1.6.5 Accessing and displaying events

To access event information:

- 1- Select a database in the Logical view.
- 2- Click the **Event Info** tab in the right hand side of the main window (VM600 MPS2 Configuration Editor).

The Event Info window is displayed, as shown in Figure 5-4.

Index	Date	Class	Type	Station	Machine	Point Tag
00014)	15.01.2004 19:35:55	ALARM	Normal	Station 1	Machine 1	BBAB 10-1000Hz /1.1
00015)	15.01.2004 19:36:01	ALARM	A+	Station 1	Machine 1	BBAB 10-1000Hz /4.1
00016)	15.01.2004 19:36:03	ALARM	A+	Station 1	Machine 1	SUM BBAB1&2
00017)	15.01.2004 19:36:03	ALARM	A+	Station 1	Machine 1	SUM BBAB1&2
00018)	15.01.2004 19:36:09	ALARM	D+	Station 1	Machine 1	BBAB 10-1000Hz /1.1
00019)	15.01.2004 19:36:09	ALARM	D+	Station 1	Machine 1	SUM BBAB1&2
00020)	15.01.2004 19:36:09	ALARM	D+	Station 1	Machine 1	BBAB 10-1000Hz /2.1
00021)	15.01.2004 19:36:09	ALARM	D+	Station 1	Machine 1	SUM BBAB1&2
00022)	15.01.2004 19:36:09	ALARM	D+	Station 1	Machine 1	BBAB 10-1000Hz /4.1
00023)	15.01.2004 19:36:09	ALARM	A-	Station 1	Machine 1	SPEED1
00024)	15.01.2004 19:36:11	ALARM	Normal	Station 1	Machine 1	BBAB 10-1000Hz /1.1
00025)	15.01.2004 19:36:11	ALARM	A+	Station 1	Machine 1	SUM BBAB1&2
00026)	15.01.2004 19:36:11	ALARM	Normal	Station 1	Machine 1	BBAB 10-1000Hz /2.1

**Figure 5-4:** Event Info window at database level

You can choose to display diagnostic events and/or alarm events by selecting the **Diagnostics** and **Alarm** check boxes under **Filters**.

To update the Event Info window at any time, click the **Refresh** button.


To remove events from the list, select one or more events then click **Delete Selected Events**.

You can use the following keyboard shortcuts to select multiple events:

- To select a contiguous (adjacent) range of events, click the first event in the range, then SHIFT+click the last event in the range.
- To select a non-contiguous (non-adjacent) range of events, CTRL+click the required events in any order.

## 5.2 Managing stations

You manage stations by selecting a station in the logical configuration tree. The main window (VM600 MPS2 Configuration Editor) resembles that shown in Figure 5-5.



**Figure 5-5:** VM600 MPS2 Configuration Editor main window at station level


On the right-hand side of the window, two tabs are available:

- Selected by default, The **General Info** tab shows information about the currently selected station:
  - **Tag**  
Allows the station name to be changed.
  - **Description**  
Optionally, some descriptive text can be entered here. This text is visible when the mouse pointer is placed on the station icon in the configuration tree.
- The **Event Info** tab shows information about events (see 5.1.6 Managing events). This tab is very similar to the window displayed at database level (see Figure 5-4), but only shows information concerning the selected station and the machines associated with it.

### 5.3 Managing machines

When you select a machine in the logical configuration tree, the main window (VM600 MPS2 Configuration Editor) resembles that shown in Figure 5-6.

In addition to the General Info tab, you can access the Timing Info and Event Info windows by clicking the tabs of the same names.



**Figure 5-6:** VM600 MPS2 Configuration Editor main window at machine level (General Info tab)

### 5.3.1 Configuring information at machine level

When you select a machine in the Logical view, the General Info tab appears by default. A typical window is shown in Figure 5-7.




Figure 5-7: General Info tab

The following programmable fields are present:

- **Tag**  
Allows the machine name to be changed.
- **Description**  
Optionally, some descriptive text can be entered here. This text is visible when the mouse pointer is placed on the machine icon in the configuration tree.

#### 5.3.1.1 Enabling and disabling data collection

The **Machine Data Collection** area of the tab contains **Enable** and **Disable** radio buttons. If you select **Enable**, data concerning the machine can be acquired and stored when the **Start** button in the toolbar of the main window (VM600 MPS2 Configuration Editor) at database level is selected. If you select **Disable**, no data will be acquired or stored for this particular machine.

The **Max Data Points** field allows you to set the maximum number of data points that will be stored per output when recording data. The data is stored in a cyclical buffer. When the maximum number of data points have been recorded, the oldest point at the beginning of the buffer are overwritten by the newest data recorded.

### 5.3.1.2 Attaching and unattaching sensors

The **Unattached Sensors** column contains a list of all the input signals associated with the machine. The entries in this list are generated by the sensor tags defined by the user during the definition of the architectural structure of the VM600 MPS. Figure 5-8 shows the **Sensor Tag** field.

The **Attached Sensors** column is used to determine the sensors that are used to acquire and store data. You include an entry in this column by first selecting it in the **Unattached Sensors** column and clicking the >> button. The associated output points then appear in the **Associated Outputs** column. You can move the entry back to the **Unattached Sensors** column by clicking the << button.

An entry can be removed from the **Attached Sensors** column by selecting it with the mouse pointer, then clicking the << button to transfer it to the **Unattached Sensors** column. When this is done, any associated output points appearing in the **Associated Outputs** column are removed.

### 5.3.1.3 Associating sensors with outputs

The **Associated Outputs** column is generated automatically by the software when the user creates a list of **Attached Sensors**. This column shows the tags defined by the user during the definition of the architectural structure of the VM600 MPS. Figure 5-8 shows the **Sensor Tag** field of a measurement channel in the Architectural view.





Figure 5-8: Sensor Tag field

Figure 5-9 shows the corresponding value of a **Tag** field for a processing channel.



**Figure 5-9:** Tag field (on Processed Output tab)

### 5.3.2 Configuring timing information

To configure timing information, select the **Timing Info** tab, as shown in Figure 5-10.

The screenshot shows the 'Timing Info' tab with the following settings:

- Alarm Mode Resolution:** 1, sec (selected), min, hour.
- Normal Mode Resolution:** 1, sec, min (selected), hour. Approximate recording time: 34 day(s), 17 hour(s). Approximate Maximum File Size: 1.544 MB.
- Averaging Interval:** 60, Normal Mode Intervals. Approximate recording time: 5 year(s), 258 day(s). Approximate Maximum File Size: 1.544 MB.
- Analog Mode Resolution:**
  - Attached Output Points:** RTD f, RTD g, RTD h, SPEED1, SPEED2.
  - Output Points (Percent):** BBAB 10-1000Hz /4.1 (3), RTD e (1).
  - Percent Change:** 0.

Figure 5-10: Timing Info tab

This tab enables you to configure parameters for the rate of data acquisition and storage. These parameters act on the signals appearing in the **Attached Output Points** column (visible on the General Info and Timing Info tabs). You can define three different cases by using the **Normal Mode Resolution**, **Averaging Interval** and **Alarm Mode Resolution** parameters.

#### 5.3.2.1 Normal Mode Resolution

The **Normal Mode Resolution** defines the acquisition rate in the absence of an alarm. Choose a time unit (seconds, minutes or hours) and then a value between 1 and 60. To view the resulting data, select the **Display Trend Chart** option from the **Machine** drop-down menu. You can define the number of acquisitions that can be stored in the Trend database, up to a maximum of 50,000. If, for example, the rate is set to 1 acquisition per minute, trend data covering a period of up to approximately 34.7 days (50,000 minutes) can therefore be displayed. See 5.3.1 Configuring information at machine level for details.

#### 5.3.2.2 Averaging Interval parameter

The **Averaging Interval** parameter acts upon the **Normal Mode Resolution** value. It allows a number of acquisitions in normal mode to be averaged and stored in a separate database

(the number of averaging intervals can be set between 1 and 100). The data obtained in this way can be displayed by selecting the **Display Averages Trend Chart** option from the **Machine** drop-down menu. The advantage of this technique is that it allows smoothed (because averaged) trend data to be obtained, and the period covered can be much longer.

For example, if the **Normal Mode Resolution** is set to 1 acquisition per minute and the **Averaging Interval** is set to 60, one averaged acquisition per hour will be stored in the Averages Trend database. This database also has a capacity of 50,000 acquisitions. In the present example, averaged trend data covering a period of up to approximately 5.7 years (50,000 hours) can therefore be displayed

### 5.3.2.3 Alarm Mode Resolution parameter

The **Alarm Mode Resolution** parameter enables the user to define an alternative acquisition and storage rate in the event of an alarm being detected (see Figure 5-11). This rate is independent of the **Normal Mode Resolution** value. You choose a time unit (seconds, minutes or hours) and then a value between 1 and 60. Data obtained in this way is stored in the Trend database (see description of Normal Mode Resolution above). Data obtained in alarm mode is not taken into account when averaged data is stored in the Averages Trend database.

### 5.3.2.4 Dynamic alarm levels

The lower part of the tab (under **Analog Mode Resolution**) allows dynamic alarm levels to be attributed to selected output points. This feature allows one acquisition to be made for all attached output points if the level of a particular signal changes by a predefined amount (either increasing or decreasing in value) since the last acquisition. In this case, an acquisition is then made for all points in the **Attached Output Points** and **Output Points (Percent)** columns of the Timing Info tab (Figure 5-10). This feature allows data to be obtained between two successive (scheduled) normal mode acquisitions (see Figure 5-11).

The next acquisition on all attached output points is made either at the scheduled acquisition time or, if the level of the signal changes again, by more than the dynamic limit that was set.

### 5.3.2.5 Output Points column


The **Output Points (Percent)** column is used to define the signals that have a dynamic alarm level applied to them. You should first select the point in the **Attached Output Points** column. Enter a percentage value (dynamic alarm limit) in the **Percent Change** field. The selected point should then be transferred to the **Output Points (Percent)** column by clicking the **>>** button. The percentage value then appears in brackets after the tag corresponding to the output point.

For example, in Figure 5-10 the signal having the tag BBAB10-1000Hz / 4.1 has had a dynamic alarm level of 3% attributed to it. This means that if the value of this signal deviates from the last acquired value by more than 3% of the full-scale deflection (FSD) value defined for the signal, data for all attached output points will be acquired once (see Figure 5-11). The FSD value is set up with **View > Architectural** chosen from the **Database** drop-down menu and the Processed Outputs \ General window selected. The value is entered in the **Full Scale Deflection** field (see Figure 5-9).

---

**NOTE:** The definition of a dynamic alarm level here does not modify the alarm levels set up for machinery protection purposes, that is, the values set up when **View > Architectural** was chosen from the **Database** drop-down menu remain unchanged. The violation of a dynamic alarm will not trip the machine, unless the (static) trip level is simultaneously exceeded. It will simply initiate one cycle of acquisitions for the attached output points.

---



**Figure 5-11:** Scheduled acquisitions, acquisitions due to dynamic alarms and acquisitions in alarm mode

### 5.3.3 Displaying event information at machine level

To display event information for a selected machine, click the **Event Info** tab. This tab is very similar to the window obtained at database level (see Figure 5-4), but only shows information concerning the selected machine.

THIS PAGE INTENTIONALLY LEFT BLANK

## 6 STORING ACQUIRED VALUES IN THE DATABASE

### 6.1 Introduction

This chapter describes how to use the VM600 MPS2 software to acquire and store data in a database for subsequent trend analysis. The trend information obtained in this way provides a useful tool for predictive maintenance of the machine being monitored.

### 6.2 Creating the Architectural and Logical configuration trees

See 4 Using VM600 MPS2 for condition monitoring for further information on the structure of the two configuration trees.

The first step is to create the architectural configuration tree to define the VM600 MPS hardware architecture. This defines a VM600 machinery protection system (MPS) in terms of database, racks and cards.

---

**NOTE:** For details on how to create the architectural configuration tree, refer to the *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual.

---

The logical configuration tree can then be built up by selecting the **View > Logical** option from the **Database** drop-down menu. This tree uses a hierarchy based on database, stations and machines (see Figure 4-1).

The following procedure should be applied for *each database* in the logical configuration tree:

- 1- Attribute one or more stations to the database. A station is defined as being a group of machines.  
See 4.2.2 *Attributing a station to a database* for further information.
- 2- Attribute one or more machines to each station.  
See 4.2.3 *Attributing machines to a station* for further information.


### 6.3 Configuring machines

Repeat the following procedure for *each machine* in the Logical View:

- 1- Switch to the Super privilege level (see 3.2 VM600 MPSx software privilege levels).
- 2- In the Logical View, select the machine from which you want to obtain data.  
The **General Info** tab appears in the main window (VM600 MPS2 Configuration Editor).  
See 5.3 *Managing machines* and 5.3.1 *Configuring information at machine level*.
- 3- Select the corresponding sensor tag names from the **Unattached Sensors** column for all signals you want to acquire and store in the database.  
Use the >> button to move the sensors to the **Attached Sensors** column.  
When this is done, the associated output points appear automatically in the **Associated Outputs** column.
- 4- Select the **Enable** button in the **Machine Data Collection** area of the General Info tab to enable data acquisition and storage for that particular machine.  
If the **Disable** button is selected, no data acquisition and storage occurs for that particular machine when the **Start** button is selected.
- 5- Select the **Timing Info** tab to set up timing parameters as necessary. See 5.3.2 *Configuring timing information*.

## 6.4 Starting the acquisition and storage of data

To start the acquisition and storage of data:


- 1- When each machine covered by the database has been set up as described in 6.3 Configuring machines, select the database in the logical configuration tree.
- 2- Click the **Start** button  on the toolbar of the main window (VM600 MPS2 Configuration Editor).

The database status flag at the bottom of the main window turns green to show that data is being acquired and stored.

---

**NOTE:** Remember that no data is acquired for a specific machine if the **Enable** button under **Signal Origin** on the General Info tab has not been selected.

---

Data acquisition and storage continues until you click the **Stop** button  in the toolbar of the main window (VM600 MPS2 Configuration Editor). When you do this, the database status flag at the bottom of the main window turns red to show that data is no longer being acquired and stored.



---

**NOTE:** Data acquisition and storage also end if the VM600 MPS2 software exited (stopped).

---

## 6.5 Modifying the Architectural structure of a VM600 MPS

If the architectural structure of a VM600 MPS needs to be modified (for example, to add new cards, or to change the configuration of a card), you must first stop the acquisition and storage of data:

- 1- Click the **Stop** button  in the toolbar of the main window (VM600 MPS2 Configuration Editor) at database level.
- 2- Select **Database > View > Architectural**.
- 3- Make the changes to the architectural structure.
- 4- Select **Database > View > Logical**.
- 5- Redefine the logical structure of the VM600 MPS as necessary.
- 6- Click the **Start** button  in the toolbar of the main window (VM600 MPS2 Configuration Editor) at database level to restart data acquisition and storage.

If you attempt to change the architectural structure without first stopping data acquisition and storage, all the fields are unavailable (greyed out) when the **View > Architectural** option is chosen.

---

**NOTE:** For more information on modifying the architectural configuration, refer to the *VM600 MPS1 Configuration Software for Machinery Protection Systems* software manual.

---

## 7 DISPLAYING DATA IN REAL-TIME

### 7.1 Introduction

This chapter describes how to display measurement data using the **Live Bar Chart** and **Live Strip Chart** commands in the **Machine** drop-down menu (Figure 7-1). These commands allow signal values to be displayed in real-time.




Figure 7-1: Machine drop-down menu

For information on displaying historical data (which has been previously acquired and stored in a database), see 8 Displaying historical data.

### 7.2 Displaying bar charts

#### 7.2.1 Overview

To display bar charts:

- 1- Select a machine from the logical configuration tree. The General Info tab appears in the main window (VM600 MPS2 Configuration Editor). (See 5.3.1 Configuring information at machine level.)
- 2- Select the **Live Bar Chart** command from the **Machine** drop-down menu. The Bar Chart Point Selection window appears (see Figure 7-2). All output points for which data exists are listed in the **Associated Outputs** column.





Figure 7-2: Bar Chart Point Selection window

3- Select the points you want represented as a bar chart (select more than one using SHIFT+click for contiguous points or CTRL+click for non-contiguous points), then transfer them to the **Display Points** column using the > button. Alternatively, transfer all points using the >> button.

4- Click the **Display** button to obtain the Machine Outputs window (see Figure 7-3).

Up to eight bar charts may be simultaneously displayed on the Machine Outputs window. The window can contain a number of sub-pages if a large number of bar charts have been generated. Each page is capable of displaying up to eight bar charts: the first page is used to display charts 1 to 8, the second page displays charts 9 to 16, and so on. You access the pages by clicking the coloured squares at the bottom of the window (see Figure 7-3).



The squares at the bottom of the window are colour coded to provide information at a glance concerning the alarm status of the bar charts (and signals) associated with each window. The colour coding is as follows:

- Green : No alarm condition exists on any of the signals.
- Yellow : Alert condition exists on one or more of the signals.
- Red : Danger condition exists on one or more of the signals.

The squares are coloured according to the worst case present on the corresponding page. If, for example, the second square is red, there is at least one signal represented by bar charts 9 to 16: that is, in a Danger condition, and others on that page may also be in an Alert condition.

## 7.2.2 Modifying the presentation of a bar chart

The presentation of individual bar charts can be altered to improve their readability. To do this, first click the bar chart you want to modify. The Bar Chart Options dialog box appears (see Figure 7-4).




Figure 7-4: Bar Chart Options dialog box

### 7.2.2.1 Modifying the scaling of a bar chart

The sequence below shows how to rescale an individual bar graph:

- 1- In the example shown in Figure 7-5, the original scaling of the chart for “RTD c” is unsatisfactory as the scale is too condensed.
- 2- Click the bar chart (RTD c) to obtain the Bar Chart Options dialog box (see Figure 7-6). Note that originally in this example the **Bar Chart Maximum** field was set to 240 and the **Bar Chart Minimum** field to -240, as shown in Figure 7-4.
- 3- Select maximum and minimum values that are closer to the measurement range of interest. For example, in Figure 7-6 the **Bar Chart Maximum** field has been set to 120 and the **Bar Chart Minimum** field to -40.
- 4- Click the **Apply/OK** button. The rescaled bar chart can be seen in Figure 7-7. To cancel any changes you have made in the Bar Chart Options dialog, if you have not already clicked **OK**, click the **Reset** button.




Figure 7-5: Bar chart “RTD c” before correction




Figure 7-6: Bar Chart Options dialog box for chart “RTD c”




Figure 7-7: Bar chart “RTD c” after correction

**7.2.2.2 Bar Chart Start at 0**

If you clear the **Bar Chart Start at 0** box in the Bar Chart Options dialog box, the bar chart starts at the **Bar Chart Minimum** value, and not at zero. See the example in Figure 7-8.

**7.2.2.3 Show Limit Labels**

If you clear the **Show Limit Labels** box in the Bar Chart Options dialog box, the Alert and Danger thresholds are removed from the bar chart. The **Bar Chart Maximum** and **Bar Chart Minimum** values are displayed. See the example in Figure 7-9.




Figure 7-8: Clearing the “Bar Chart Start at 0” box




Figure 7-9: Clearing the “Show Limit Labels” box

### 7.2.3 Drop-down menu commands for bar charts

The Machine Outputs window for bar charts contains the two drop-down menus as shown in Figure 7-10.

In the **File** drop-down menu, the **Print** command allows the currently displayed bar charts to be printed.

In the **Options** drop-down menu, the **Freeze** command allows the currently displayed bar charts to be frozen. If the **Freeze** command is selected (see Figure 7-10), then Freeze is turned on and the currently displayed bar charts will not be updated. Select this command again to clear the check mark and turn off Freeze.



Figure 7-10: Drop-down menus for bar charts (in Machine Outputs window)

## 7.3 Displaying strip charts

### 7.3.1 Overview

A strip chart resembles an oscilloscope trace. The VM600 MPS2 software enables up to 16 strip charts to be displayed on a single window. Additional charts can be displayed on sub-pages.

To display strip charts:

- 1- Use the mouse pointer to select a machine from the logical configuration tree. The General Info tab appears by default in the main window (VM600 MPS2 Configuration Editor). (See 5.3.1 Configuring information at machine level.)
- 2- Select the **Live Strip Chart** command from the **Machine** drop-down menu. The Bar Chart Point Selection window appears (Figure 7-2). All output points for which data exists are listed in the **Associated Outputs** column.
- 3- Highlight with the mouse pointer the points you want represented as a strip chart (select more than one using SHIFT+click for contiguous points or CTRL+click for non-contiguous points), then transfer them to the **Display Points** column using the > button. Alternatively, transfer all points using the >> button.
- 4- Click the **Display** button to obtain the Machine Outputs window. The charts are immediately displayed in real time. An example is shown in Figure 7-11.

Drop-down menu commands allow charts to be printed, and data to be displayed in tabular form. See 7.3.2 Drop-down menu commands for strip charts for a description of all the commands.

The horizontal and vertical axes of the strip chart are set by default, but you can zoom to areas of particular interest (you must freeze the display before doing this). This is described in 7.3.3 Sizing, repositioning and zooming.


To use the cursor feature, click with the mouse pointer on the chart at the point of interest. The Cursor Box window opens (see Figure 7-12). The title bar of this window shows the date and time of the acquisition. The signal values at that moment in time are shown in the window,

along with the measurement units, the rectifier function and the full-scale deflection (FSD) value. The figure in the **% Max** column expresses the measured value as a percentage of the FSD.

To define the period over which the chart is plotted, select the **Realtime** command from the **Setup** drop-down menu. The Realtime Display Setup dialog box appears (Figure 7-13). Enter an acquisition rate (minimum value 1 second) in the **Scan Rate** field. The overall duration of the real-time acquisition should be defined by selecting the appropriate button under **Realtime Display Period** (values from 1 minute to 1 hour can be selected).

When more than 16 strip charts are displayed, colour-coded squares at the bottom of the window provide information at a glance concerning the alarm status of the charts (and signals) associated with each window, as shown in Figure 7-11. The colour coding is as follows:

- Green : No alarm condition exists on any of the signals.
- Yellow : Alert condition exists on one or more of the signals.
- Red : Danger condition exists on one or more of the signals.



Buttons only visible when more than 16 charts displayed

- (1) Button to view charts 17 to 32 on the screen.
- (2) Alarm summary indicator for charts 17 to 32.  
(colour indicates worst case present among the 16)
- (1) Button to view charts 1 to 16 on the screen.
- (2) Alarm summary indicator for charts 1 to 16.  
(colour indicates worst case present among the 16)

**Figure 7-11:** Typical strip chart display (Machine Outputs window)




Figure 7-12: Typical strip chart display with the Cursor Box window open





Figure 7-13: Realtime Display Setup dialog box

### 7.3.2 Drop-down menu commands for strip charts

The Machine Outputs window for strip charts contains seven drop-down menus as shown in Figure 7-14.



**Figure 7-14:** Drop-down menus for strip charts (in Machine Outputs window)

- To print the currently displayed strip charts, choose **Print** from the **File** menu.
- To obtain a data summary for each curve displayed, choose **Data** from the **Info** menu. A Data Summary window as shown in Figure 7-15 appears. The **End Date** and **No. of Points** relate to the moment at which the data summary was requested, and do not change over time. The strip charts, however, continue to evolve in real time in the background. To display a data summary for another signal, simply click the name of the signal (for example BBAB10-1000Hz\_4) from the list of names appearing at the bottom of the Machine Outputs window.
- In the **Setup** drop-down menu, choose the **Realtime** command to display the Realtime Display Setup dialog box (Figure 7-13). This enables you to define the duration (x-axis) of the strip chart. The **Display** command of the **Setup** drop-down menu is not operational for strip charts.
- You can present the strip charts displayed in the Machine Outputs window in tabular form by selecting the **Tabulate** command from the **Data** drop-down menu. You must first freeze the display by selecting **Freeze** from the **Options** drop-down menu. A Tabulated Data window resembling that shown in Figure 7-16 appears. This shows the acquisition time and the value recorded. The figure in the **% Max** column expresses the measured value as a percentage of the FSD. To display tabular data for another displayed signal, simply click the name of the signal (for example BBAB10-1000Hz\_4) from the list of names appearing at the bottom of the Machine Outputs window. If there are many points stored for a machine, the tabulated display can take a long time. To reduce the waiting time, define a lower value for the **Max Data Points** field on the General Info tab of the Machine window. See 5.3 Managing machines.
- The **Zoom** drop-down menu enables you to reset the horizontal and vertical axes of the strip chart to their default values. This is useful if these values have been changed by sizing, repositioning and zooming (see 7.3.3 Sizing, repositioning and zooming). Furthermore, the Zoom command is useful when you have a large number of points stored for a machine. In this case the tabulated display can take an appreciable length of time. Using Zoom restricts the area to be tabulated to the values of interest, and so requires less time.

- In the **Options** drop-down menu, the **Freeze** command allows the currently displayed strip charts to be frozen. This operation is necessary before displaying data in tabular form (Figure 7-16), or performing sizing, repositioning and zooming operations (see 7.3.3 Sizing, repositioning and zooming). If the **Freeze** command is selected, the check mark can be cleared and Freeze turned off by select this command again.




Figure 7-15: Typical strip chart display with the Data Summary window open




Figure 7-16: Tabulated Data Window

### 7.3.3 Sizing, repositioning and zooming

You can size, reposition and zoom strip charts and trend charts using a combination of keystrokes (SHIFT, CTRL) and mouse buttons.

---

**NOTE:** For strip charts, you must first freeze the display by selecting **Freeze** from the **Options** drop-down menu (see 7.3.2 Drop-down menu commands for strip charts).

---

The keystroke operations are summarised below.

#### 7.3.3.1 Chart sizing (CTRL + <MOUSE-Middle>)

- 1- Hold down the CTRL key and the wheel (middle) mouse button (or both the left and right buttons on a two-button mouse).
- 2- Drag the mouse pointer up the screen to reduce the size of the chart and drag it down the screen to increase the size.

#### 7.3.3.2 Chart repositioning (SHIFT + <MOUSE-Middle>)

- 1- Hold down the SHIFT key and the wheel (middle) mouse button (or both the left and right buttons on a two-button mouse) to attach the chart to the mouse pointer.
- 2- You can then drag the chart and drop it anywhere in the display window.

#### 7.3.3.3 Scaled window zooming (SHIFT + <MOUSE-Left>)

- 1- Hold down the SHIFT key and drag the left mouse button to form a rectangular window containing the area of interest on the chart.
- 2- When you release the mouse button, the display is zoomed to the rectangle and the X- and y- axis scales are refreshed.

#### 7.3.3.4 Unscaled window zooming (CTRL + <MOUSE-Left>)

- 1- Hold down the CTRL key and drag the left mouse button to form a rectangular window containing the area of interest on the chart.
- 2- When you release the mouse button, the display is zoomed to the rectangle. However, in this case the x-axis and y-axis scales are not refreshed.

#### 7.3.3.5 Reset (r)

- 1- Press the r key to reset the horizontal and vertical axes of the trend chart to their default values.

This is the same as choosing the **Reset** command from the **Zoom** drop-down menu.

---

**NOTE:** This operation is case-sensitive and does not work with the R key.

---

**THIS PAGE INTENTIONALLY LEFT BLANK**

## 8 DISPLAYING HISTORICAL DATA

### 8.1 Introduction

This chapter describes the **Historic Trend Chart** and **Historic Trend Chart (Averages)** commands in the **Machine** drop-down menu (Figure 8-1). These commands enable historical data (which has been previously acquired and stored in a database) to be displayed.

This provides an insight into the progression of measured values over a period of time (the period covered can range from several days to several years, depending on how the user sets up the acquisition parameters). The historical trend charts obtained in this way provide a useful tool to help perform predictive maintenance of the machine being monitored.




Figure 8-1: Machine drop-down menu

For information on displaying data in real-time, see 7 Displaying data in real-time.

## 8.2 Displaying historical trend charts

### 8.2.1 Overview

To display historical trend charts:


- 1- Use the mouse pointer to select a machine from the logical configuration tree. The General Info tab appears by default in the main window (VM600 MPS2 Configuration Editor). (See 5.3.1 Configuring information at machine level.)
- 2- Select the **Historic Trend Chart** command from the **Machine** drop-down menu. The Trend Chart Point Selection window appears (Figure 8-2). All output points for which data exists are listed in the **Associated Outputs** column.
- 3- Highlight with the mouse pointer the points you want to chart, then transfer them to the **Display Points** column using the > button (select more than one using SHIFT+click for contiguous points or CTRL+click for non-contiguous points). Alternatively, you can transfer all points using the >> button.
- 4- Click the **Display** button to obtain the Historic Trend Chart window (Figure 8-3).

The drop-down menu commands enable charts to be printed and data to be displayed in tabular form. See 8.2.2 Drop-down menu commands for trend charts for a description of all the possibilities.


The horizontal and vertical axes of a historical trend chart are set by default but you can zoom to areas of particular interest. This is described in 7.3.3 Sizing, repositioning and zooming.

To use the cursor feature, click with the mouse pointer on the chart at the point of interest. The Cursor Box window opens (Figure 8-4). The title bar of this window shows the date and time of the acquisition. The signal values at that moment in time are shown in the window, along with the measurement units, the rectifier function and the full-scale deflection (FSD) value. The figure in the % **Max** column expresses the measured value as a percentage of the FSD.

### 8.2.1.1 Updating the historical trend chart display

If you are displaying historical trend data while at the same time continuing to record data in real-time, when new data is detected, the **Refresh** button (  ) under the Info menu becomes enabled. Click this button to update the display with the current new data.

### 8.2.1.2 Changing plot background colour

You can select either a dark or light background colour for the display by clicking the **Plot Background Colour** button (  ), under the File menu.




Figure 8-2: Trend Chart Point Selection window




Figure 8-3: Typical Historic Trend Chart window





Figure 8-4: Typical Historic Trend Chart window with the Cursor Box open

## 8.2.2 Drop-down menu commands for trend charts

The Historic Trend Chart window contains six drop-down menus, as shown in Figure 8-5.



**Figure 8-5:** Drop-down menus for historical trend charts (in Trend Chart window)

- To print the currently displayed trend charts, choose **Print** from the **File** menu.
- To obtain a data summary for each curve displayed, choose **Data** from the **Info** menu. A Data Summary window resembling that shown in Figure 8-6 appears. The **Start Date**, **End Date** and **No. of Points** relate only to the part of the curve displayed. To display a data summary for another signal, simply click the name of the signal from the list of names appearing at the bottom of the Historic Trend Chart window.
- To display the Display Setup dialog box, choose the **Display** command from the **Setup** drop-down menu. From this box you can choose to display the alarm levels on the Historic Trend Chart (select the Alarms check box to do this). You can also display vertical and/or horizontal grid lines on the chart by selecting the x-axis and/or y-axis check boxes, respectively.
- To specify the start and stop date and times of the data to display, select the **Time Filter** command from the **Setup** menu. You can then choose the start and end of the time interval to be displayed, from a standard Windows Date/Time control.
- You can present the trend charts displayed in the Historic Trend Chart window in tabular form by selecting the **Tabulate** command from the **Data** drop-down menu. A Tabulated Data Window resembling that shown in Figure 8-7 appears. This shows the acquisition time and the value recorded. The figure in the **% Max** column expresses the measured value as a percentage of the FSD. To display tabular data for another displayed signal, simply click the name of the signal from the list of names appearing at the bottom of the Historic Trend Chart window.
- The **Zoom** drop-down menu allows you to reset the horizontal and vertical axes of the strip chart to their default values. This is useful if these values have been changed by sizing, repositioning and zooming (see 7.3.3 Sizing, repositioning and zooming).
- The **Options** drop-down menu is not operational for Trend Charts and Averages Trend Charts.




Figure 8-6: Typical Historic Trend Chart window with the Data Summary window open




Figure 8-7: Typical Tabulated Data Window

## 8.3 Displaying averages trend charts

### 8.3.1 Overview

The approach to displaying averages trend charts is very similar to that for normal trend charts. See 8.2 Displaying historical trend charts for further information.

To display averages trend charts:

- 1- Use the mouse pointer to select a machine from the logical configuration tree.  
The General Info tab appears by default in the main window (VM600 MPS2 Configuration Editor). (See 5.3.1 Configuring information at machine level.)
- 2- Select the **Historic Trend Chart (Averages)** command from the **Machine** drop-down menu. The Trend Chart (Averaging) Point Selection window appears (Figure 8-8).  
All output points for which data exists are listed in the **Associated Outputs** column.
- 3- Highlight with the mouse pointer the points you want to chart, then transfer them to the **Display Points** column using the > button (select more than one using SHIFT+click for contiguous points or CTRL+click for non-contiguous points). Alternatively, you can transfer all points using the >> button.
- 4- You can display one or more of the following curves: minimum values, maximum values or averaged values.  
Choose the curve(s) you want to display by selecting the **Minimum Values**, **Maximum Values** or **Average Values** check boxes, as appropriate.
- 5- Click the **Display** button to obtain the Historic Trend Chart (Averages) window (Figure 8-9).

The drop-down menu commands enable charts to be printed and data to be displayed in tabular form. See 8.2.2 Drop-down menu commands for trend charts for a description of all commands.

The horizontal and vertical axes of the trend chart are set by default, but you can zoom to areas of particular interest. This is described in 7.3.3 Sizing, repositioning and zooming.

To use the cursor feature, click with the mouse pointer on the chart at the point of interest. The Cursor Box window opens (Figure 8-10). The title bar of this window shows the date and time of the (averaged) acquisition. The minimum and maximum values found for each signal while calculating the average value are displayed in the **Min** and **Max** columns respectively. The average value of the values considered is shown for each signal in the **Avg** column.




Figure 8-8: Trend Chart (Averaging) Point Selection window




Figure 8-9: Typical window for a Historic Trend Chart (Averages)

Tag	Min	Max	Avg
SPEED1	66.17	67.59	66.73

Figure 8-10: Cursor Box for a Historic Trend Chart (Averages)

### 8.3.2 Further information

The window for a Historic Trend Chart (Averages) contains the same drop-down menus as seen in Figure 8-5.

The only difference to note is the aspect of the Tabulated Data Window obtained by selecting the **Tabulate** command from the **Data** drop-down menu (see Figure 8-11). For a Historic Trend Chart (Averages), the **Start Date** column shows the times at the middle of each group of acquisitions (that is, if the average of *n* normal mode acquisitions is taken to put in the Historic Trend Chart (Averages) database, the time corresponds to the time at which acquisition number *n/2* was taken). The **Min** and **Max** columns show the minimum and maximum values found for the signal during each block of *n* acquisitions. The average value of these *n* acquisitions is shown for each time interval in the **Avg** column.

To display tabular data for another displayed signal, simply click the name of the signal in the list of names appearing at the bottom of the Historic Trend Chart (Averages) window.

Index	Start Date	Min (Hz)	Max (Hz)	Avg (Hz)
00105	04.02.2004 15:53:00	53.29	59.49	56.24
00106	04.02.2004 15:54:00	59.64	66.09	62.46
00107	04.02.2004 15:55:00	66.17	67.59	66.73
00108	04.02.2004 15:56:00	67.66	68.03	67.88

Figure 8-11: Typical Tabulated Data Window for a Historic Trend Chart (Averages)

## 9 CUSTOMER SUPPORT

### 9.1 Contacting us

Meggitt Sensing Systems' worldwide customer support network offers a range of support including 9.2 Technical support and 9.3 Sales and repairs support. For customer support, contact your local Meggitt Sensing Systems representative. Alternatively, contact our main office:

Customer support  
Meggitt SA  
Route de Moncor 4  
PO Box 1616  
CH-1701 Fribourg  
Switzerland

Telephone: +41 (0)26 407 11 11  
Email: [energysupport@ch.meggitt.com](mailto:energysupport@ch.meggitt.com)  
Web: [www.meggittsensing.com](http://www.meggittsensing.com)

### 9.2 Technical support

Meggitt Sensing Systems' technical support team provide both pre-sales and post-sales technical support, including:

- 1- General advice
- 2- Technical advice
- 3- Troubleshooting
- 4- Site visits.

---

**NOTE:** For further information, contact Meggitt Sensing Systems (see 9.1 Contacting us).

---

### 9.3 Sales and repairs support

Meggitt Sensing Systems' sales team provide both pre-sales and post-sales support, including advice on:

- 1- New products
- 2- Spare parts
- 3- Repairs.

---

**NOTE:** If a product has to be returned for repairs, then it should be accompanied by a completed Failure report form, included on page 9-3.

---

## 9.4 Customer feedback

As part of our continuing commitment to improving customer service, we warmly welcome your opinions. To provide feedback, complete the Customer feedback form on page 9-5 and return it Meggitt Sensing Systems' main office (see 9.1 Contacting us).

# FAILURE REPORT FORM

If the product has to be returned to Meggitt Sensing Systems for repairs, then:

- 1- Complete this failure report form.
- 2- Attach a photocopy of this report to the faulty unit and retain the original copy for your records.
- 3- Send the product together with the attached failure report form to Meggitt SA by registered post.

---

**NOTE:** Please provide as much information as possible in order to assist fault diagnosis.

---



---

**NOTE:** A failure report must be sent with each faulty product.

---

**Contact details:**

Name \_\_\_\_\_ Job title \_\_\_\_\_

Company \_\_\_\_\_ Email \_\_\_\_\_

Address \_\_\_\_\_

Country \_\_\_\_\_ Post code \_\_\_\_\_

Telephone \_\_\_\_\_ Fax \_\_\_\_\_

Signature \_\_\_\_\_ Date \_\_\_\_\_

**Product details:**

Product type: \_\_\_\_\_

Serial number (S/N): \_\_\_\_\_ Part number (P/N): \_\_\_\_\_

Meggitt SA order number: \_\_\_\_\_

Date of purchase: \_\_\_\_\_ Site where installed: \_\_\_\_\_

**Is the failure** (put an  where appropriate):

- Continuous?                       Intermittent?                       Temperature dependent?

**Description of failure:**

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

*(Continue overleaf)*





